

For Exit Only Models

For Exit Only Models:

There shall be no exterior trim or release of the lock.

For Entry Models With Cylinder & Pull Handle (industrial applications):

Exterior trim shall be a stainless steel plate with a hardened steel cylinder protector and "breakaway" pull handle. The pull handle shall be affixed to the trim plate via a preening method without the use of screws or other fasteners. In the event of undue force or vandalism, the pull handle is to separate from the trim.